


Podłączenie i konfiguracja telefonu VoIP Gigaset A580IP

- * Podłączenie urządzenia
- * Konfiguracja do działania we FreecoNet Gigaset A580 IP



Podłączenie urządzenia Gigaset A580IP

Podłącz słuchawkę oraz stację bazową zgodnie z instrukcją, która znajduje się na płycie CD w pudełku. Jeśli nie posiadasz instrukcji możesz ją pobrać na stronie sklepu partnerskiego www.4ip.pl.



Konfiguracja telefonu VoIP Gigaset A580IP

Naciśnij niebieski przycisk na bazie telefonu. Na wyświetlaczu słuchawki wyświetli się adres IP bazy.

Wpisz odczytany adres w pasku adresu przeglądarki internetowej, wyświetli się strona:

Gigaset A580 IP



The login screen features a 'Login' button in an orange bar at the top left. Below it, a 'Welcome' message explains the interface's purpose and security. A language dropdown menu is set to 'English'. A system pin input field with four dots and an 'OK' button is provided for authentication. On the right, there is a 3D illustration of the device and a help icon.


SIEMENS

Copyright © 2008 Gigaset Communications GmbH. All rights reserved.
Manufactured by Gigaset Communications GmbH under trademark license of Siemens AG.

Domyślne hasło to: 0000 (cztery zera).

Przejdź do zakładki Settings -> Telephony -> Connections

Gigaset A580 IP



The 'Connections' screen is divided into three sections: IP Connection, Gigaset.net, and Fixed Line Connection. The IP Connection section contains a table with 6 rows, each representing an IP provider. The Gigaset.net section shows a single entry for 'Gigaset.net' which is registered and active. The Fixed Line Connection section shows a single entry for 'Fixed Line'.

	Name / Provider	Suffix	Status	Active
1.	IP1 Other Provider	#1	Disabled	<input type="checkbox"/>
2.	IP2 Other Provider	#2	Disabled	<input type="checkbox"/>
3.	IP3 Other Provider	#3	Disabled	<input type="checkbox"/>
4.	IP4 Other Provider	#4	Disabled	<input type="checkbox"/>
5.	IP5 Other Provider	#5	Disabled	<input type="checkbox"/>
6.	IP6 Other Provider	#6	Disabled	<input type="checkbox"/>

	Name	Suffix	Status	Active
	Gigaset.net	#9	Registered	<input checked="" type="checkbox"/>

	Name	Suffix	Active
	Fixed Line	#0	<input type="checkbox"/>

SIEMENS

Wybierz Edit.

Gigaset A580 IP

Home Settings Status Log Off

IP Configuration

Telephony

Connections

Audio

Number Assignment

Call Forwarding

Dialling Plans

Network Mailbox

Advanced Settings

Messaging

Info Services

Handsets

Miscellaneous

1. IP Connection

You can replace the default name with a name or the actual phone number to distinguish this connection.

Connection Name or Number:

Auto Configuration

If your provider has issued you with a configuration code, you can use it to start the automatic connection configuration here.

Auto Configuration Code:

Provider: Other Provider

Personal Provider Data

Authentication Name:

Authentication password:

Username:

Display name:

SIEMENS

Wybierz: Select VoIP Provider.

Gigaset A580 IP

Home Settings Status Log Off

IP Configuration

Telephony

Connections

Audio

Number Assignment

Call Forwarding

Dialling Plans

Network Mailbox

Advanced Settings

Messaging

Info Services

Handsets

Miscellaneous

Provider Selection

With selection of a provider most of the configuration data (General Provider Data, Listen Ports, Network, Codecs) for this provider are loaded automatically.

There are two steps necessary to get the configuration data:

- Choose country of your VoIP provider.
- Choose your VoIP provider.

To continue, click Next.

SIEMENS

Kliknij Next.

Gigaset A580 IP

Home Settings Status Log Off

IP Configuration
Telephony
Connections
Audio
Number Assignment
Call Forwarding
Dialling Plans
Network Mailbox
Advanced Settings
Messaging
Info Services
Handsets
Miscellaneous

Provider Selection ?

Please choose the country from the list you want to load the provider list for.

Poland

< Back Next > Cancel

SIEMENS

Wybierz kraj: Poland i kliknij Next.

Gigaset A580 IP

Home Settings Status Log Off

IP Configuration
Telephony
Connections
Audio
Number Assignment
Call Forwarding
Dialling Plans
Network Mailbox
Advanced Settings
Messaging
Info Services
Handsets
Miscellaneous

Provider Selection ?

Please choose the provider from the list you need the configuration data from.

Freeconet

< Back Finish > Cancel

SIEMENS

Wybierz: FreecoNet i kliknij Finish.

Podaj swoje dane.

Authentication Name:

Twój login FreecoNet

Authentication password:

Twoje Hasło VoIP

Username:

Twój login FreecoNet

Display name:

Twój login FreecoNet

Gigaset A580 IP

Home Settings Status Log Off

IP Configuration

Telephony

Connections

Audio

Number Assignment

Call Forwarding

Dialling Plans

Network Mailbox

Advanced Settings

Messaging

Info Services

Handsets

Miscellaneous

1. IP Connection

You can replace the default name with a name or the actual phone number to distinguish this connection.

Connection Name or Number:

Auto Configuration

If your provider has issued you with a configuration code, you can use it to start the automatic connection configuration here.

Auto Configuration Code:

Provider: Freeconet

Personal Provider Data

Authentication Name:

Authentication password:

Username:

Display name:

SIEMENS

Kliknij Set.

Konto powinno się zalogować do FreecoNet.

Gigaset A580 IP

Home Settings Status Log Off

IP Configuration

Telephony

Connections

Audio

Number Assignment

Call Forwarding

Dialling Plans

Network Mailbox

Advanced Settings

Messaging

Info Services

Handsets

Miscellaneous

IP Connection

	Name / Provider	Suffix	Status	Active
1.	jan_kowalski Freeconet	#1	Registered	<input checked="" type="checkbox"/>
2.	IP2 Other Provider	#2	Disabled	<input type="checkbox"/>
3.	IP3 Other Provider	#3	Disabled	<input type="checkbox"/>
4.	IP4 Other Provider	#4	Disabled	<input type="checkbox"/>
5.	IP5 Other Provider	#5	Disabled	<input type="checkbox"/>
6.	IP6 Other Provider	#6	Disabled	<input type="checkbox"/>

Gigaset.net

Name	Suffix	Status	Active
Gigaset.net	#9	Registered	<input checked="" type="checkbox"/>

Fixed Line Connection

Name	Suffix	Active
Fixed Line	#0	<input type="checkbox"/>

SIEMENS

Przejdź do zakładki Audio i w oknie "Selected codecs" pozostaw: G.729 oraz G.711.

Gigaset A580 IP

The screenshot shows the 'Settings for Bandwidth' section of the Gigaset A580 IP web interface. The left sidebar contains a navigation menu with 'Audio' highlighted. The main content area includes a 'Settings for Bandwidth' section with a descriptive paragraph about VoIP call quality. Below this are radio buttons for 'Allow 1 VoIP call only' (set to No) and 'Voice Quality' (set to 'Own Codec preference'). The 'Settings for Connections' section shows the user 'jan_kowalski' and 'Volume for VoIP Calls' set to 'Normal'. There are two lists: 'Selected codecs' containing G.729, G.711 a law, and G.711 μ law; and 'Available codecs' containing G.726 and G.722. The 'Settings for Codecs' section has 'Enable Annex B for codec G.729' set to No. 'Set' and 'Cancel' buttons are at the bottom.

SIEMENS

Przejdź do zakładki Advanced Settings i wprowadź następujące ustawienia:

Send settings:

RFC 2833

Use the R key to initiate call transfer with the SIP Refer method:

Yes

Transfer Call by On-Hook:

Yes

Derive target address:

from SIP contact header

Find target addr. automatically:

No

Gigaset A580 IP

The screenshot shows the 'DTMF over VoIP connections' section of the Gigaset A580 IP web interface. The left sidebar has 'Advanced Settings' highlighted. The main content area includes a 'DTMF over VoIP connections' section with 'Send settings' set to 'RFC 2833'. Below is a 'Call Transfer' section with 'Use the R key to initiate call transfer with the SIP Refer method.' set to Yes, 'Transfer Call by On-Hook' set to Yes, 'Derive target address' set to 'from SIP contact header', and 'Find target addr. automatically' set to No. The 'Hook Flash (R-key)' section has a note: 'R key settings are disabled because the R key is being used for call transfer.' The 'Listen ports for VoIP connections' section has 'Use random ports' set to No, 'SIP port' set to 5060, and 'RTP port' set to 5004 - 5020. 'Set' and 'Cancel' buttons are at the bottom.

SIEMENS

Kliknij Set.

Twój telefon Siemens Gigaset A 580 IP jest gotowy do użycia !

Jeżeli telefon VoIP zarejestruje się poprawnie do platformy zadzwoń testowo na numer FreecoNet sprawdzający stan Twojego konta. W tym celu wybierz 901 na klawiaturze telefonu a automat poda Ci jakie jest saldo.